

Tabelle1

Akku Entladen

LemonRC 1300

Anfangsladung:

1550

Ampere	Spannung
0	12,1
450	9,6
760	9,2
828	9
864	8,8
887	8,6
909	8,4
924	8,2
936	8
945	7,8
952	7,6
957	7,4
962	7,2

Entladediagramm




Tabelle2

Akku Entladen Enrichpower 1500 2/3A 7 Zellen 8.4V

Geladen: ca 2000 bei 0.2A

Spannung	Ampere
9900	0
9800	5
9700	11
9600	19
9500	29
9400	42
9300	57
9200	78
9100	97
9000	117
8900	145
8800	179
8700	228
8600	405
8500	682
8400	853
8300	917
8200	932
8100	937
8000	957
7900	966
7800	969
7700	971
6800	990
6700	1064
6600	1118
6500	1157
6400	1188
6300	1209

